



# **Installation Instructions for Comcork Flooring Products**

Profiles include:  
Walk Easy, Low Profile,  
Textured, Aquadeck  
and Tactiles.

**Issue Date: July 2023**

**FDRI Pty Ltd  
7-15 Valley Street  
Oakleigh South, Victoria 3167  
Australia.**

**Ph: 61 3 8329 4800**

**Email: [administration@visitindustrial.com.au](mailto:administration@visitindustrial.com.au)**

## Contents

1.	Important Note .....	2
2.	Experienced Contractors & Relevant Standards .....	2
3.	Subfloors .....	2
4.	Particle Board Sub - Floors (Not exposed to weather elements).....	3
5.	Under - Floor Heating .....	3
6.	Adhesives .....	4
7.	Installation .....	5
8.	Adhesive Bonding Time.....	6
9.	Point Loading .....	6
10.	Sharp Objects .....	6
11.	Seam Sealing .....	7
12.	Protecting the Floor After Laying .....	7
13.	Maintenance & Surface Dressing.....	7
14.	Comcork Flooring Tactiles.....	7
15.	Appendix – Recommended Product List:.....	9

## Scope

This document sets out the installation instructions for Comcork Flooring in either smooth or interrupted profiles:

Comcork Walk Easy surface profile	smooth & general purpose
Comcork Low Profile surface profile	slightly raised small round stud
Comcork Textured Surface Profile	overall orange peel textured
Comcork AquaDeck surface profile	raised small stud in either diamond or round pattern
Comcork Tactiles (Tactile ground surface indicators for the vision impaired - TGSIs)	Hazard, studded profile Directional, ribbed profile

### 1. Important Note

**It is strongly recommended that floor coverings are not installed in direct sunlight as like all materials they expand and contract with temperature. Once adhered properly, Comcork Floor coverings exhibit excellent stability.**

**Due to the natural characteristics of cork used in the manufacture of Comcork Flooring, some slight variation in shade and texture between sheets may occur.**

**The manufacturer recommends that possible shade variation and texture match is checked before bonding more than one sheet in an adjacent area.**

### 2. Experienced Contractors & Relevant Standards

Installation should be carried out by a fully experienced contractor. The installer shall be experienced and conversant with all aspects of the floorcovering trade. He should be familiar with the preparation and treatment of all sub-floors, underlays troweled and rigid, adhesives storage and application. It is also desirable that he be aware of the various installation instructions as recommended by flooring manufacturer, adhesive manufacturers and the Australian Standard 1884-2012 "Laying of Resilient Sheet & Tile Floor Coverings".

### 3. Subfloors

Comcork Flooring is suitable for installing on level, clean and dry sub - floors including concrete, trowel able underlay, synthetic underlays, hardboard underlays, marine plywood, aluminum, steel and fiberglass. All of these must comply with the Australian and New Zealand minimum Standards.

Sub-floors must be clean, dust free, dry, smooth and hard before laying. Uneven solid or timber sub-floors may need preparation to meet the required standard.

The nominated contractor is responsible for the inspection, moisture testing and the required preparation of the sub-floor prior to the installation of Comcork Flooring Products.

### 3.1 Concrete Sub – Floors

Concrete sub - floors must be dry, level, rigid, smooth, clean, (free of wax, oil, paint, alkali) and free of hydrostatic pressure (refer to A.S. 1884-2012 for definitions).

Concrete in contact with fill, hardcore or ground, must have a suitable impermeable membrane underneath to prevent ingress of moisture. Concrete must be thoroughly cured, dry, and free of any curing agents.

**All concrete sub-floors** shall be subjected to a shear testing procedure to test the suitability of the surface to accept the adhesive bonding of the floorcoverings.

Concrete sub-floors should be tested for moisture using only a certified apparatus to accurately determine the level of moisture within the sub-floor. A written record of all moisture tests shall be carefully maintained in chronological order and be available for inspection if required.

**All concrete sub-floors** must be free of moisture prior to installation otherwise proper adhesion will not be achieved. Do not install Comcork when relative humidity of concrete sub-floor exceeds 75% (ASTM F2170).

### 3.2 Timber Sub - Floors

Ensure adequate sub-floor ventilation

All new work shall comply with the relevant standards, in particular timber flooring as in A.S. 1684 Part 1 Section 3. Particleboard A.S. 1080 Part 1, Plywood AS 2098 Part 1.

It is recommended that all timber floors old or new be level sanded and that hardboard underlay be fixed as recommended by the hardboard manufacturer.

## 4. Particle Board Sub - Floors (Not exposed to weather elements)

Particle board floors should be level sanded and hardboard underlay be fixed as recommended by the hardboard manufacturer

The floor **should not** be fixed directly to the particle board as this is likely to result in show through of particleboard seams and possible damage to floorcovering if particle board expands and contracts.

### 4.1 Steel, Aluminum, Fibreglass Sub – Floors

Substrates must be clean, dry, free of grease, oil and other contaminants. The surfaces should be fully abraded to allow adhesive “keying”.

## 5. Under - Floor Heating

Where sub-floors incorporate under-floor heating. (Typically refers to concrete floors that have heating coils laid directly into the concrete.)

## 5.1 Existing Floors

### 5.1.1 Acrylic Adhesive Installation

- Heating should be turned off 48 hours prior to installation to allow the slab enough time to totally cool down.
- Heating must remain off, for 7 days after installation.
- After 7 days the temperature should then be increased progressively over the next 7 days to its normal operating high.

### 5.1.2 Epoxy & Polyurethane Adhesive Installation

- Heating should be turned off 48 hours prior to installation to allow the slab enough time to totally cool down.
- Heating must remain off, for 48 hours after installation.
- After 48 hours the temperature should then be increased progressively over the next 48 hours to its normal operating high.

### 5.1.3 New Floors

Procedure is as above except that the heating system should be turned on to the maximum normal operating range and kept on for 24 hours per day for 7 days prior to the heating being switched off for 48 hours.

## 6. Adhesives

Comcork Flooring must be installed with an approved adhesive suitable for the area and sub-floor. **This adhesive must be applied in strict accordance to the manufacturer's recommended instructions.**

- **Refer to the Appendix for a list of approved adhesives.**
- **The adhesives must be spread with a 1.6 mm V notched trowel.**

It is recommended that a new trowel blade be used with each installation as the amount and spread of glue will change significantly with continued use of a worn trowel. Having the correct adhesive coverage and ensuring that good transference has been achieved to the back of the flooring material is critical in achieving a successful installation

### 6.1 Primers

In some circumstances it may be necessary to apply a primer before the adhesive. The primer is used on substrates to help settle dust, reduce adhesive dispersing into the sub-floor, increasing bond strength and spread rates. Consult your local distributor for further advice.

The primer may be spread with a short nap roller or 1.6 mm 'V' notched trowel in accordance with the manufacturers instructions

Note: Primers are for use with water based and acrylic based adhesives only. Epoxy and Polyurethane adhesives do not normally require floor priming.

## 7. Installation

### 7.1 Site Acclimatization

All flooring products should be removed from packaging and stored flat for at least 24 hours prior to being installed. This will allow the material to acclimatize to site conditions.

### 7.2 Dry Laying - Assessing for colour and textural variation

As with all-natural cork products, some variation in colour may occur.

**Comcork Flooring MUST BE dry laid** so that any possible shade variation and texture match is checked and rectified before bonding

### 7.3 Brick Pattern

**Comcork Flooring MUST BE laid in a brick pattern**

### 7.4 Butt Joints

Comcork Flooring should be laid end to end to ensure a close butt joint is achieved. **For optimum results these joints should be taped together using an appropriate masking tape**, especially when using epoxy/polyurethane adhesives which have no initial tack. Remove the masking tape immediately after the adhesive has cured (no longer than 24hrs after installation).

Do not push the joints in too tightly as this can cause peaking.

### 7.5 Rolling

Progressively roll the floor with a 3 sectioned roller as the floor is laid.

Laying must be followed by careful rolling with a 35 - 45kg multi-wheel roller to ensure the exclusion of air and to achieve proper transfer of the adhesive on to the back of the material, providing maximum bond to the sub-floor.

**Do not leave heavy objects on the floor for at least 24 hours after installation.**

### 7.6 Removing Excessive Adhesive

Excess adhesive must be removed immediately from the surface of the floor before curing using clean damp cloth (water only). Trying to remove adhesive, once cured, is most likely to cause damage to the flooring surface. If adhesive has been left to cure on the surface aggressive rubbing must be avoided. Use a damp cloth and try to peel the adhesive away from the surface.

## 7.7 Installation using Epoxy or Polyurethane Adhesive

All substrates must be clean, dry, free of grease, oil and other contaminants. Steel, Aluminum, Fiberglass and other very smooth surfaces should be abraded as required before applying epoxy adhesive.

**Mixing and application of two-part epoxy adhesive must be strictly as specified by the adhesive manufacturer.**

**The adhesive must be spread with a 1.6mm V notched trowel and the flooring laid into the wet film of adhesive.**

### Note:

Epoxy and Polyurethane adhesive does not possess wet or dry tack properties - it relies upon the thickness of adhesive film to hold down the material. Should the material not lay flat (e.g. peaking edges) then assistance must be given by holding down the edges with weights until partial cure of the adhesive has taken place. This also applies to areas around waste drains which are normally graded down towards the drain. It is normal to weight these with a sand bag (bag filled with loose sand) until the adhesive has cured.

Excess adhesive must be removed immediately from the surface of the floor before curing using a damp clean cloth (water only). Excess adhesive once set, cannot be easily removed, and in trying to remove, will most likely to cause damage to the floor surface.

## 8. Adhesive Bonding Time

### 8.1 Acrylic Adhesive

Floor traffic should be avoided ideally for 24 hours but **for a minimum 12 hours** after installation.

### 8.2 Epoxy or Polyurethane Adhesive

Floor traffic should be avoided ideally for 48 hours but **for a minimum 24 hours** after installation.

## 9. Point Loading

Comcork Flooring is extremely durable and will easily withstand significant load bearing impact. Excessive localised point loading should be avoided and the use of protective load spreading caps are advisable in such situations.

## 10. Sharp Objects

Care should be taken to protect the floor from sharp objects such as metal stools and table legs. These should always have appropriate protective caps.

## 11. Seam Sealing

Because of the unique composition of Comcork Flooring, thermoplastic welding is not suitable. For certain installations it may be necessary to seam weld the joints using a cold weld, such as in areas where a high standard of hygiene is required.

The delivery of seam sealer should be of a design to allow maximum sealer into the joint so that the two vertical faces of each adjoining sheet are sufficiently coated to form an impermeable link.

## 12. Protecting the Floor After Laying

Once installation is complete the finished floor should be protected from damage during any further stages of construction by laying a non- abrasive protective covering.

### **Heavy objectives**

Heavy objects should never be dragged across the floor at any stage.

## 13. Maintenance & Surface Dressing

A floor dressing provides an added protective coating, which helps to protect the floor from dirt and grit, enhancing its appearance and making the floor much easier to maintain.

Dressings are formulated to maximize durability and resistance to scuffing.

It is recommended that Comcork Flooring be sealed unless in a wet area application or where maximum slip resistance is required. \*

An effective maintenance program is necessary to help preserve the appearance, durability and safety of Comcork Flooring. The level of maintenance required will vary according to the amount and type of foot traffic and other site conditions.

For information on how to best maintain Comcork Flooring refer to the Comcork Flooring Maintenance Instructions (available from the Comcork Distributor in each state).

\* Sealing will significantly affect the wet anti- slip performance. It is the responsibility of the building owner to assess the appropriate level of slip resistance in all cases

## 14. Comcork Flooring Tactiles

Comcork flooring Tactiles are special flooring tiles with a significantly raised profile designed to provide the visually impaired a warning of impending hazards or give directional guidance.

**Comcork Flooring Tactiles are available in two profiles**

- **Warning of hazard indicators (Large studded profile)**
- **Direction of travel indicators (Large ribbed pattern)**



Comcork Flooring Tactiles should be installed in accordance with the requirements of Australian Standards AS 1884 - 2012 and the Comcork Flooring Installation Instructions - Please refer to your local distributor for detailed Comcork Tactile Installation instructions.

They must be set out for different installation circumstances in the manner prescribed in The Australian Standards AS 1428.4 - 2009 Part 4: Tactile ground surface indicators for the orientation of people with visual impairment.

Comcork Tactiles are suitable for both wet and dry conditions

Comcork Tactiles should be installed using the recommended adhesives as outlined in the Approved adhesives list - refer to your local distributor for detailed Comcork Tactile Installation Instructions.

## 15. Appendix – Recommended Product List:

### Adhesive

Brand	PRODUCT NAME	DESCRIPTION
Mapei	Ultrabond Eco VS90 Plus	Domestic & commercial hard-set solvent free acrylic adhesive. For use in <b>dry interior areas only</b> . Suitable for installing Comcork’s Walk Easy, Low Profile, Ergo, Poly Cork, and Tactile products to subfloors types outlined in the Installation Instructions.
Mapei	Adesilex G19	Domestic & commercial two-part epoxy-polyurethane adhesive. For <b>use in wet interior and dry/wet exterior areas</b> . Suitable for installing Comcork’s Walk Easy, Low Profile, Ergo, Poly Cork, Aquadeck and Tactile products to internal & external subfloors types outlined in the Installation Instructions.

### Sealer

Type	PRODUCT NAME	DESCRIPTION
Acrylic	Peerless JAL Hyshield Matte Finish	Easy to apply, high durability.
Polyurethane	Peerless JAL Dr. Schutz	2 Part water borne polyurethane sealer. Approved applicator required.

### WARNING

**Recommended maintenance products are detailed throughout this procedure. Substitute products with high solvent content aggressive or abrasive chemicals must not be used. Do not use high speed maintenance machinery or aggressive methods on Comcork products.**

**Note that Ammonia based products must never be used to maintain floors which are top dressed with sealer as this will lead to premature failure of the surface dressing.**

**Refer to your Comcork Distributor for all maintenance enquiries.**